

NextGenRoto AquaStairs



Installation Instructions

Congratulations on your purchase of our new and improved NextGenRoto AquaStairs, and to make your life easy, we have put together the following installation instructions.

You will notice you have received two U-bolts for each handrail. You will need to insert the stainless-steel handrails into the predrilled holes. Once you set the height of the handrails identify where you need to drill holes into the stairs, insert the U-bolts do up the nuts on the inside of the stairs



Once the handrails are secured, tighten all the nuts and you are ready to place your stairs into the water.

You will also need ballast to stabilise your AquaStairs in your pool.

There are several options for this:

- 150mm plumbing pipe, available from your local hardware store with 2 end caps, then fill that with rapid set concrete
- Several house bricks
- Concrete pavers
- Heavy stones

It is important to ensure that ballast is clean. We do not recommend using bags of sand as it may leach out and be difficult to remove if needing to adjust the stairs.

So now it's time to go relax and enjoy your brand new AquaStairs.